

Annexure-1: A typical LP Moving Blade Drawing indicating the hardened area where hardness needs to be measured.

