Rotary Hearth Furnace - Zonal - Pre Heaters + Control Panel

PR No: 0133704240, date: 05.04.2023

Sl. No.	Heating Capacity Required (kW)	Maximum Flow Rate (LPH)	No. of Heaters Required
1	16	120	2
2	36	300	4

## **Total No. of Pre Heaters with Control Panel**

6

## Note to Supplier:

- 1. The indented items are required for pre heating the Very Low Sulphur Furnace Oil at Rotary Hearth Furnace prior to Oil entry at Burner Nozzles.
- 2. Pre Heater shall be connected in line with Entry and Exit flanges of Oil Pipe line and pipe is of size 1 inch.
- 3. Oil entry at ambient temperature and exit needs to be controlled and Heated to the maximum temperature of 200°C.
- 4. Oil Pre Heater and its control panel as per the specification sheet, any deviation should be mentioned in the Offer without fail.
- 5. The Oil Pre Heater and Control Panel works in conjunction with each other. Hence Pre Heater and Control Panel should be considered as a single package and quote accordingly.